



MELLOTT PARTS LIST
SLAB KICKOFF & DUAL PURPOSE KICKOFF & TRANSFER

REF. NO.	PART NO. SLAB KO	PART NO. DUAL PURPOSE	DESCRIPTION	QTY. REQ.
1	571-DWHO	----	Foot Switch (Electric)	1
2	NP 1-7/16	NP 1-7/16	Bearing, Pillow Block	8,9,10
3	13-4201	13-4201	Roll, 6-5/8 dia. x 24" face	8,9,10
	13-4202	13-4202	Roll, 6-5/8 dia. x 24" face w/ shaft extension	
4	----	1033388-D	Push Button Station	1
5	10-4201	10-4201	Foot Pad	
6	1" Jam	1" Jam	Hex Nut	
7	10-4701*	10-6501*	Roll Case Frame 16'	1
	10-4702*	10-6502*	" " " 18'	
	10-4703*	10-6503*	" " " 20'	
8	MSB	MSB	Flangette	8,9,10
9	GC1107KRRB	GC1107KRRB	Bearing	8,9,10
10	MSA	MSA	Flangette	8,9,10
11	04-4201	04-4201	Chain	
12	DS6013	DS6013	Sprocket, Double 13T	8,9,10
13	10-4202	10-4202	Key, Tapered	8,9,10
14	11-41A01	11-41A01	Deflector/Shear Rail	
15	CHB-38-70011	----	Timing Relay	1
16	RB11-PC	----	Base, Plug In	1
17	AHG-6X6X6	----	Enclosure	1
18	SO4	SO4	Solenoid Valve, (Air)	1,2
19	06A21A18A1BA	06A21A18A1BA	Filter, REGulator, Lubricator 3/8"	1
20	10-5004	10-5004	Plate, FRL	1
21	10-4704*	10-4704*	Kickoff Arm Assembly	1
22	NP 1-15/16	NP 1-15/16	Bearing, Pillow Block	2,6
23	11-5001*	11-6501*	Frame, Butterfly	1
24	10-5005	10-5005	Shaft & Counterweight	1
25	10-5006	10-5006	Belt, Butterfly	1
26	802T-H	802T-AT	Limit Switch	1
27	802T-W1	802T-W1	Roller Lever	1
28	6912-B	6912-B	Bearing	2
29	10-5007	10-5007	Cam	1
30	MP-I 5 x 8	MP-I 5 x 8	Air Cylinder	1
31	11-5002*	11-6502*	Butterfly Assembly	1
32	10-4203	10-4203	Shield, Drive Chain 10'	
	10-4204	10-4204	" " " 8'	
	10-4205	10-4205	" " " 6'	
33	13-4203	13-4203	Roll, 6-5/8 dia. x 24" face, Rubber Covered (Optional - used as last roll before Green Chain)	
34	----	A-12N126	Enclosure	1
35	----	RB08-PC	Base, Plug In	2
36	----	KRP11AG	Relay	2
37	----	CHB-38-70011	Timing Relay	2
38	----	RB11-PC	Base, Plug In	2
39	H60	H60	Chain	
40	H60P	H60P	Pin, Chain (H60)	
41	----	1-1/2 HP 1800 RPM	Electric Motor	1
42	----	2/3V x 2.65	Sheave	1
43	----	2/3V530	V-Belt	1
44	----	JA 7/8	Bushing	1
45	----	107D25	Speed Reducer w/ Tie Rod Assembly	1
46	----	10-6504*	Shield, Drive	1
47	----	2/3V x 5.6	Sheave	1
48	----	SH 3/4"	Bushing	1
49	----	10-6505*	Skid, Live Stop	1
		10-6506*	Skid, Fixed Stop	1
50	----	10-6507	Guard, Shaft	3
51	----	16-6953	Shaft, Live Stop	1
		10-6508*	Skid, Live Stop	2
52	----	10-6509*	Skid, Fixed Stop	3
53	----	10-6907	Arm, Live Stop	3
54	----	16-5007	Shaft, Head	1
55	----	18-6012-2	Sprocket	4
56	----	SF 1-7/16	Bearing, 4 Bolt Flange	4
57	----	10-6510*	Skid, Live Stop	1
58	----	10-6511*	Sill w/Legs	1
59	----	SFT 1-7/16	Bearing, 2 Bolt Flange	4
60	----	10-6906*	Arm, Live Stop	1
61	----	490 2-1/2 x 6	Air Cylinder	1
62	----	FO4	Foot Valve Air	1
63	----	960 3-1/2 x 10	Air Cylinder	1
64	----	10-6512*	Sill w/Legs	1
65	----	10-6513*	Drop Out Arm Assembly	1

* Note: For Left Hand Units use L.H. as Part Number Suffix.

Earlier units may have different control components (Ref.No. 15,16,35,36,37,38).
Order replacement parts by component name and number on equipment.