



MELLOTT MFG. CO.	
DATE	DRAWN BY
1/77/83	TKL
TILT HOIST	
LANDING TRANSFER #164	

MELLOTT PARTS LIST

LANDING TRANSFER - ITEM 164 (FOR TILT HOIST)

<u>REF. NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY. REQ.</u>
1	16-5001	SHAFT	
2	18-8105-0	SPROCKET, 5T PLASTIC IDLER	
3	*	UHMW PLASTIC WEAR STRIP	
4	81XP	PIN	
5	81X	CHAIN	
6		BASE PIN (FOR 960 X 6)	1
7	960 X 6"	AIR CYLINDER	1
8		CLEVIS (FOR 960 X 6)	1
9		CLEVIS PIN (FOR 960 X 6)	1
10	10-6902-2	1-7/16" LIVE STOP ARM	1
	10-6902-3	1-15/16" LIVE STOP ARM	1
11	16-16401*	SHAFT	
12	16-16402*	LIVE STOP SHAFT	
13	10-6904-2	1-7/16" LIVE STOP ARM	
	10-6904-3	1-15/16" LIVE STOP ARM	
14	SC 1-7/16"	2-BOLT FLANGE BEARING	
	SC 1-15/16"	2-BOLT FLANGE BEARING	
15	18-8112-3	SPROCKET, 81X, 12T	
16	SC 1-15/16"	4-BOLT FLANGE BEARING	
17	80SF26	SPROCKET	1
18	SF 1-15/16"	BUSHING	1
19	04-16404	CHAIN, RC80 X 86 PITCHES	1
20	R73DT90L4 29 RPM	2 H.P. GEARMOTOR	1
21	80SDS14H	SPROCKET	1
22	SDS 1-5/8"	BUSHING	1
23	10-16401	ADJUSTMENT BOLT	1
24	10-16402*	SHIELD	1
25	1-1/2" N.C.	FULL NUT	8
26	10-16403	FOOT PAD	
27	*	4" TRUSSED CHANNEL SKIDS	
28	*	CROSS SILL	
29	*	CROSS SILL	

* COMPLETE DESCRIPTION INCLUDING HAND AND/OR SIZES ARE NECESSARY TO ORDER REPLACEMENTS

MELLOTT MFG. CO., INC., 13156 LONG LANE, MERCERSBURG, PA 17236
 TEL. 717-369-3125 / FAX. 717-369-2800